

# Body Dimensional Drawings



## Opening Repair Chart

Unit: mm (in)


<Doors/Windshield Opening>

Ⓑ  
At the lower edge of the second trim panel installation slot on the front pillar inner.


NOTE:  
● This sketch shows the measuring points of body.  
● The dimensions of above list shows the design value of distance between the black dots shown in detail sketches.



Ⓐ Windshield lower depression bead




Ⓒ Windshield opening flange notch




Ⓓ, Ⓔ, Ⓕ Door opening area flange notch


<Rear Window/Rear Hatch/Trunk Lid Opening>





Ⓒ Rear upper rail flange notch




Ⓗ Rear bulkhead center flange notch




Ⓘ Side panel outer flange notch



Ⓙ, Ⓚ Trunk front gutter depression bead



Ⓛ Trunk gutter edge of the flange



Ⓜ Rear panel flange mark

# Body Dimensional Drawings

## Frame Repair Chart

