

# Service Precautions

## Supplemental Restraint System (SRS)

The NSX Supplemental Restraint System (SRS) includes a driver's side airbag, located in the steering wheel hub, a passenger's airbag, located in the dashboard above the glove box, and seat belt pretensioners, located in the seat belt retractors.

NOTE: The following precautions should be observed when performing sheet metal work, paint work and repair work around the locations of the SRS parts.

- ① SRS dash sensors are located under the dashboard. Avoid strong impact with a hammer or other tools when repairing the front side frame and the lower part of the dashboard. Do not apply heat to these areas with a torch, etc.
- ② SRS harnesses are located under the lower part of the dashboard below the dashboard panel. (SRS harnesses are covered with a yellow corrugated tube.) Care should be taken not to damage the harness when repairing this area.
- ③ Do not apply heat of more than 212°F (100°C) when drying painted surfaces anywhere around the locations of SRS parts.
- ④ If strong impact or high temperature needs to be applied to the areas around the locations of SRS parts, remove the part before performing repair work.
- ⑤ If any of the SRS related parts are damaged or deformed, be sure to replace them.

NOTE: Refer to the Service Manual (Supplemental Restraint System) for removal and replacement of SRS related parts.

