


# Cross Section of Body and Sealants/Adhesive Caulking

NOTE: Seal the following areas to prevent air leaks, water leaks, and rust.


► : Sealing locations

Hood:


Spot Sealer: 3M #08892 (Internal)  
: 3M #08893 (External)



## Dashboard Upper and Front Side Frame:



## Front Wheelhouse:




VIEW A


(cont'd)

# Cross Section of Body and Sealants/Adhesive Caulking

## Outside panel and Roof Panel:




## Door:



**Front Floor (forward), Dashboard Lower, Front Side Frame and Side sill.**

NOTE: Do not fill up with sealant to the cruise control actuator cable through hole.



(cont'd)

# Cross Section of Body and Sealants/Adhesive Caulking

Side Sill, Front Floor (rearward) and Rear Bulkhead Center:

