


# Reverse Idler Gear




## Installation

1. Install the reverse idler gear.



2. Set the spring in the reverse idler shaft. Push the spring in with the steel ball then install the needle bearing.

NOTE: The steel ball is under spring pressure. Take care not to let it pop out.



3. Install the reverse idler shaft holder into the transmission housing, then tighten the bolts.

