

Manual Transmission

Special Tools	13-2
Maintenance	
Transmission Oil	
'91-'95 Models	13-3
'96 Model	13-2
Back-up Light Switch, Neutral Position Switch	
Replacement	13-3
Gearshift Mechanism	
Overhaul	13-4
Cable Adjustment	
'91-'92 Models	13-5
'93-'96 Models	13-5
Transmission Assembly	
Removal	
'91-'92 Models	13-6
'93-'94 Models	13-6
'95-'96 Models	13-6
Component Location	
Index	
'91-'92 Models	13-10
'93-'94 Models	13-10
'95-'96 Models	13-10

Reassembly	
'91-'92 Models	13-43
'93-'94 Models	13-43
'95-'96 Models	13-43
Installation	
'91-'92 Models	13-48
'93-'94 Models	13-48
'95-'96 Models	13-48
Transmission Housing	
Removal	
'91-'92 Models	13-12
'93-'94 Models	13-12
'95-'96 Models	13-12
Reverse Shift Arm, Reverse Shift Fork	
Clearance Inspection	13-13
Reverse Idler Gear Shaft Assembly	
Removal	13-14
Disassembly/	
Reassembly	13-15
Reverse Shift Fork Assembly	
Disassembly/	
Reassembly	13-16

Mainshaft, Countershaft, Differential Assemblies	
Removal	13-16
Shift Lever, Select Lever	
Removal	13-17
Change Holder Assembly	
Disassembly/	
Reassembly	13-19
Change Holder Assembly, Shift Fork	
Clearance Inspection	13-20
Shift Fork, Syncro Sleeve	
Clearance Inspection	13-21
Shift Fork Assembly	
Disassembly/	
Reassembly	13-22
Mainshaft Assembly	
Component Location	
Index	13-23
Clearance Inspection	13-24
Disassembly	13-25
Inspection	13-26
Reassembly	13-27

Countershaft Assembly	
Component Location	
Index	13-29
Clearance Inspection	13-30
Disassembly	13-31
Inspection	13-32
Reassembly	13-33
Synchro Ring, Gear	
Inspection	13-35
Synchro Sleeve, Synchro Hub	
Inspection	13-36
Installation	13-36
Oil Pump	
Disassembly/	
Reassembly	13-37
Clearance Inspection	13-38
Countershaft Bearing (Clutch Housing)	
Replacement	13-39
Mainshaft Oil Seal (Clutch Housing)b	
Replacement	13-40
Mainshaft Thrust Shim	
Adjustment	13-41