

Body Dimensional Drawings

Opening Repair Chart

Coupe:




Unit: mm (in)

< Doors/Windshield Opening >


NOTE:

- This sketch shows the measuring points of body.
- The dimensions of above list shows the design value of distance between the black dots shown in detail sketches.


Ⓑ
At the lower edge of the second trim panel installation slot on the front pillar inner.



Ⓐ
Windshield lower
depression bead




Ⓒ
Windshield opening
flange notch




Ⓓ, Ⓔ, Ⓕ, Ⓖ
Door opening area
flange notch



< Rear Window/Rear Hatch/Trunk Lid Opening >




H Rear upper rail
flange notch




I Rear bulkhead center
flange notch



J Trunk front gutter
depression bead



K Trunk gutter edge
of the flange



L Rear panel
flange mark