


Entry Light Timer System

Component Location Index


SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS [section 24](#) before performing repairs or service.

Description: If the driver's door has been opened by the outer handle, the foot well light and a light at the ignition switch go on and stay on for about eight seconds after the driver's door has been closed.

FOOT WELL LIGHT
Replacement, page [23-231](#)



DRIVER'S DOOR SWITCH
(Built into the door lock actuator assembly)
Test, page [23-206](#)



UNDER-DASH FUSE BOX

ENTRY LIGHT TIMER CIRCUIT
(Built into the integrated control unit)
Input Test, page [23-167](#)