

# Brakes

## Conventional Brake

Special Tools .....	19-2
Component Location Index .....	19-3
Inspection and Adjustment	
Rubber Parts and Brake	
Booster .....	19-4
Pedal Height .....	19-5
Parking Brake .....	19-5
Front Brakes	
Index/Inspection .....	19-6

Front Brake Pads	
Inspection/Replacement .....	19-7
Front Caliper	
Disassembly .....	19-9
Reassembly .....	19-10
Front Brake Disc	
Runout Inspection .....	19-10
Thickness and Parallelism	
Inspection .....	19-11
Bleeding .....	19-11

Master Cylinder and Brake Booster	
Index/Torque .....	19-13
Master Cylinder Inspection .....	19-14
Brake Booster Tests .....	19-15
Pushrod Clearance	
Adjustment .....	19-16
Rear Brakes	
Torque/Inspection .....	19-17
Rear Brake Pads	
Inspection/Replacement .....	19-18

Rear Brake Disc	
Runout Inspection .....	19-20
Thickness and Parallelism	
Inspection .....	19-21
Rear Caliper	
Disassembly .....	19-21
Reassembly .....	19-24
Brake Hoses/Lines	
Inspection .....	19-27
Parking Brake	
Disassembly/Reassembly ...	19-28

## Anti-lock Brake System (ABS)

Features/Construction/Operation	
'97-99 Models .....	19-29
'00-05 Models .....	19-3c
Component Locations	
'97-99 Models .....	19-38
'00-05 Models .....	19-2c
ABS Control Unit Terminal	
Arrangement	
'97-99 Models .....	19-42
'00-05 Models .....	19-6c
Troubleshooting Precautions	
'97-99 Models .....	19-46
'00-05 Models .....	19-8c

Diagnostic Trouble Code (DTC)	
Indication	
'97-99 Models .....	19-48
'00-05 Models .....	19-10c
DTC Clearing	
('00-05 Models) .....	19-11c
Troubleshooting Index	
'97-99 Models .....	19-49
'00-05 Models .....	19-12c
ABS Function Test .....	19-74
Hydraulic System	
Hydraulic Connections .....	19-76
Relieving Accumulator/	
Line Pressure .....	19-77
Modulator/Solenoid Unit	
Index/Torque .....	19-78

Solenoid Leak Test .....	19-79
Solenoid Flushing .....	19-80
ABS Modulator-Control Unit	
('00-05 Models)	
Removal/Installation .....	19-29c
Power Unit	
Torque/Inspection .....	19-81
Accumulator/Pressure Switch	
Index/Torque .....	19-82
Removal .....	19-83
Accumulator Disposal .....	19-83
Bleeding	
Air Bleeding with ALB	
Checker .....	19-84

Electronic Components	
ABS Control Unit	
Replacement .....	19-85
Relay Inspection .....	19-86
ABS Indicator Relay	
('00-05 Models)	
Inspection .....	19-30c
Pulsers/Sensors	
Inspection	
'97-99 Models .....	19-86
'00-05 Models .....	19-30c
Front Sensor	
Replacement .....	19-87
Rear Sensor	
Replacement .....	19-87
Wheel Sensor Replacement	
('00-05 Models) .....	19-31c

## Traction Control System (TCS)

Special Tools .....	19-90
Component Locations .....	19-91
System Description	
Outline .....	19-92
Construction and	
Function .....	19-93

TCS Control Unit Terminal	
Arrangement .....	19-98
Troubleshooting	
TCS Indicator Light .....	19-100
Troubleshooting Guide .....	19-102

Electronic Components	
TCS Switch Inspection .....	19-123
Lateral Acceleration (Lg) Sensor	
Inspection .....	19-123

Steering Angle Sensor	
Replacement .....	19-124
TCS Control Unit	
Replacement .....	19-126