


Wheel Sensor Replacement

NOTE: Be careful when installing the sensors to avoid twisting the wires.

Front

☆: CORROSION RESISTANT BOLT

☆ 6 x 1.0 mm
9.8 N-m (1.0 kgf-m, 7.2 lbf-ft)



☆ 6 x 1.0 mm
9.8 N-m (1.0 kgf-m,
7.2 lbf-ft)


☆ 8 x 1.25 mm
22 N-m (2.2 kgf-m,
16 lbf-ft)

Rear

☆: CORROSION RESISTANT BOLT

☆ 8 x 1.25 mm
22 N-m (2.2 kgf-m, 16 lbf-ft)

☆ 6 x 1.0 mm
9.8 N-m (1.0 kgf-m, 7.2 lbf-ft)



☆ 6 x 1.0 mm
9.8 N-m (1.0 kgf-m,
7.2 lbf-ft)

☆ 6 x 1.0 mm
9.8 N-m (1.0 kgf-m,
7.2 lbf-ft)