




Solenoid Test

1. Disconnect the 3P connector of the reverse lockout solenoid.
2. Measure the resistance between No. 1 and No. 3 terminals.

Standard: 10.74 – 11.86 Ω




Terminal side of male terminals.

If the resistance is not within the standard, replace the reverse lockout solenoid.

3. Test reverse lockout solenoid operation by connector battery power to the No. 1 terminal and ground to the No. 3 terminal. A clicking sound should be heard.
4. If the reverse lockout solenoid no clicking sound is heard, replace it.

Solenoid Replacement

1. Disconnect the 3P connector.



2. Remove the reverse lockout solenoid from the transmission.
3. Remove the select lock pin and select lock return spring.
4. Install the reverse lockout solenoid in the reverse order of removal.