

# Steering

\*: Read [SRS precautions](#) before working in this area

Special Tools .....	17-2
Component Location Index	
Manual Steering .....	17-18f
Power Steering .....	17-3
System Description	
Steering Column .....	17-4
Energy-absorbing Steering Column/Wheel .....	17-6
Electrical Power Steering (EPS) .....	17-7
Major Components .....	17-8
System Operation .....	17-9
Function and Operation ...	17-10
Component Locations .....	17-16

EPS Control Unit Terminal Arrangement .....	17-20
Troubleshooting Precautions	
'97-99 Models .....	17-22
'00-'05 Models .....	17-2c
Diagnostic Trouble Code (DTC)	
Indication .....	17-23
Symptom-to-System Chart	
'97-99 Models .....	17-25
'00-'05 Models .....	17-3c
Troubleshooting Flowcharts	
Hard Steering .....	17-26

Inspection	
Steering Wheel Rotational Play .....	17-42
Power Assist Check .....	17-42
Steering Gearbox Adjustment .....	17-42
Steering Wheel	
*Removal .....	17-43
*Disassembly/ Reassembly .....	17-44
*Installation .....	17-45
Steering Column	
*Removal .....	17-47
Inspection .....	17-49
*Installation .....	17-50

Steering Gearbox	
Manual Steering	
Removal/Installation ...	17-19f
Component Location	
Index .....	17-21f
Disassembly .....	17-22f
Reassembly .....	17-25f
Ball Joint Boot	
Replacement .....	17-30f
Power Steering	
Removal/Installation ...	17-53
Component Location	
Index .....	17-57
Inspection .....	17-58
Ball Joint Boot	
Replacement .....	17-61
EPS Control Unit	
Replacement .....	17-62