


Component Locations


Index




(cont'd)

Component Locations

Index (cont'd)





**PGM-FI
MAIN RELAY**
Relay Testing, page 11-143
in the 1997 NSX Service Manual
Troubleshooting, page 11-144
in the 1997 NSX Service Manual



ENGINE CONTROL MODULE (ECM)
Self-diagnostic Procedures, page 11-38
in the 1997 NSX Service Manual
Troubleshooting, page 11-61
in the 1997 NSX Service Manual

SERVICE CHECK CONNECTOR (2P)
Self-diagnostic Procedures
page 11-38 in the 1997 NSX Service Manual





DATA LINK CONNECTOR (16P)
Self-diagnostic Procedures, page [11-38](#)
in the 1997 NSX Service Manual

(cont'd)

Component Locations


Index (cont'd)

THROTTLE BODY (TB)

Inspection, page [11-151](#)
in the 1997 NSX Service Manual
Disassembly, page [11-152](#)
in the 1997 NSX Service Manual

AIR CLEANER (ACL)

Disassembly, page [11-149](#)
in the 1997 NSX Service Manual



INTAKE AIR DUCT


INTAKE AIR BYPASS (IAB) CONTROL DIAPHRAGM

Troubleshooting, page [11-155](#)
in the 1997 NSX Service Manual
Test, page [11-157](#)
in the 1997 NSX Service Manual

INTAKE AIR BYPASS (IAB) VALVE BODY ASSEMBLY

POSITIVE CRANKCASE VENTILATION (PCV) VALVE

Troubleshooting, page [11-50](#)
Inspection, page [11-52](#)
Replacement, page [11-52](#)



FUEL PUMP RELAY
Troubleshooting, page [11-139](#)
in the 1997 NSX Service Manual

