




Power Antenna Motor Test

1. Open the trunk lid, and remove the side trim panel.
2. Disconnect the 4P connector from the motor, and check power to the motor at the connector terminals:
 - There should be battery voltage between the WHT/BLU (+) and BLK (-) terminals all the time.
 - There should be battery voltage between the PNK/WHT (+) and BLK (-) terminals only with the ignition and radio switched ON.



3. Test motor operation:

FULL EXTEND: Connect battery power to the No. 3 and No. 4 terminals and ground to the No. 2 terminal.

RETRACT: Disconnect power from the No. 3 terminal.

4. If the motor fails to operate properly, replace it.

