



Disassembly

NOTE:

- Handle the terminals and printed circuit boards carefully to avoid damaging them.
- Replace the speedometer, trip meter, and printed circuit board A as a unit if any of them is faulty.
- Replace the tachometer, odometer, and printed circuit board B as a unit if any of them is faulty.

SPEEDOMETER MOUNTING SCREWS (x3)

TACHOMETER MOUNTING SCREWS (x3)

VOLTAGE/FUEL GAUGE MOUNTING SCREWS (x5)

COOLANT TEMP/ENGINE OIL PRESSURE GAUGE MOUNTING SCREWS (x6)

HOUSING

SAFETY INDICATOR MOUNTING SCREWS (x2)

COOLANT TEMPERATURE/ ENGINE OIL PRESSURE GAUGE

Test, page [23-136](#) and [23-137](#)

SHIFT INDICATOR

- TACHOMETER
Specification, page [23-121](#)
- A/T GEAR POSITION
INDICATOR
See page [23-152](#)

ODOMETER

SPEEDOMETER

Specification, page [23-121](#)

FUEL/VOLTAGE GAUGE

Test, page [23-121](#)
and [23-134](#)

TRIP METER

LIGHT HOUSING

FACE PANEL

VISOR

PRINTED CIRCUIT BOARD B

BOARD-TO-BOARD CONNECTOR

PRINTED CIRCUIT BOARD COVER

TRIP METER RESET BUTTON

SAFETY INDICATOR

See page [23-147](#)

PRINTED CIRCUIT BOARD A