




Fan Relay Tests


Check continuity at the relay terminals.

- There should be continuity between the C and D terminals.
- There should be continuity between the A and B terminals when power and ground are connected to the C and D terminals.
- There should be no continuity between the A and B terminals when power is disconnected.

• Radiator fan low relay



- Radiator fan high relay
- Condenser fan relay



Engine compartment fan relay (A/T)

