


Driveshafts

Disassembly

1. To remove the boot band, pry up the locking tabs with screwdriver, and raise the end of the band.


NOTE: Carefully clamp the driveshaft in a vise with soft jaws.

CAUTION: Take care not to damage the boots.




2. Mark each roller and joint to identify the locations of rollers and grooves in the joint.

NOTE: Be careful not to drop the rollers when separating them from the inboard joint.




3. Remove both joints.

Outboard joint side only: Remove the circlip from the outboard joint groove, then remove the outboard joint and spring.



4. Mark the rollers and spider to identify the locations of rollers on the spider, then remove the rollers.

BEARING REMOVER
(Commercially available)



5. Mark the spider and driveshaft to identify the position of the spider on the shaft.
6. Remove the set ring.
7. Remove the spider using a bearing remover.
8. Remove the stop rings from the driveshaft.