




A/T Gear Position Switch Replacement

SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS [section 24](#) before performing repairs or service.

1. Remove the center console panel and dashboard (see [section 20](#)).
2. Disconnect the 12P and 2P connectors from the A/T gear position switch.




3. Remove the two position switch mounting bolts.
4. Position the slider on the new switch to **N** as shown above.
5. Shift the shift lever to **N**, then slip the switch into position.
6. Attach the switch with the two bolts.
7. Test the switch in the **P** and **N** positions. You should be able to start the engine with the shift lever in position **N** anywhere in the range of free play.
8. Connect the 12P and 2P connectors, clamp the harness, and install the dashboard and center console panel.

Bulb Replacement

SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS [section 24](#) before performing repairs or service.

1. Remove the gauge assembly (see page [23-126](#)).
2. Disassemble the gauge assembly (see page [23-129](#)).
3. Remove the bulb from printed circuit board B.



4. Install the indicator in the reverse order of removal.