



# Reverse Idler Gear Shaft Assembly

## Removal

1. Remove the reverse shift arm from the clutch housing.




2. Shift the reverse shift fork to the driven gear side.
3. Remove the reverse shift fork assembly.





4. Remove the reverse idle gear shaft assembly.



**REVERSE IDLE GEAR  
SHAFT ASSEMBLY**