


Opener/Latch

Trunk Lid Opener Actuator Replacement

Canadian Models

NOTE: Put on gloves to protect your hands.

1. Remove the left trunk side trim panel.
2. Remove the trunk lid opener actuator.
 - 1 Disconnect the trunk lid opener actuator connector.
 - 2 Remove the actuator mounting bolts.
 - 3 Disconnect the trunk lid opener cable.



3. Install the trunk lid opener actuator in the reverse order of removal, and note these items:
 - Make sure the actuator connector is plugged in properly and the opener cable is connected properly.
 - Check the operation of the actuator; the trunk lid opens properly.