




Transmission Control Module (TCM)

Replacement

SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS (section 24) before performing repairs or service.

- 1. Remove the seat back panels (see section 20).
- 2. Remove the connector holder from the TCS control unit, and disconnect the antenna lead.
- 3. Remove the TCS control unit.

NOTE: Do not disconnect the connectors from the TCS control unit.



- 4. Disconnect the A (26P) and B (22P) connectors from the TCM, then remove the TCM.

