


## ABS Indicator Relay

### Inspection

1. Check for continuity between terminals ① and ③. There should be continuity.
2. Connect a 12 V battery across terminals ② and ④. There should be no continuity between terminals ① and ③.



## Pulsers/Wheel Sensors

### Inspection

1. Check the front and rear pulser for chipped or damaged teeth.
2. Measure the air gap between the wheel sensor and pulser all the way around while rotating the pulser. If the air gap exceeds specification, check for a bent suspension arm.

#### Standard:

Front/Rear 0.4 - 1.0 mm (0.02 - 0.04 in)

#### Front/Rear

