



# Differential

## Illustrated Index

### NOTE:

- If the parts marked with an asterisk (\*) are replaced, the bearing preload must be adjusted (see page 15-12).
- If replacement is required, always replace the limited slip differential clutch set.

