




A/T Gear Position Switch Test

1. Remove the front console, then disconnect the 12P connector from the A/T gear position switch.
2. Check for continuity between the terminals in each switch position according to the table.
 - Move the lever back and forth at each position without touching the push button, and check for continuity within the range of free play of the shift lever.
 - If there is no continuity within the range of free play, adjust the position of the A/T gear position switch (see page [23-162](#)).



A/T Gear Position Switch (For cruise control)

Terminal Position	5	8
1		
2		
3/M		
D		
N		
R		
P		