


Horns


Horn Test

1. Disconnect the 2P connectors from the horns.
2. Remove the right and left horns.

Right (High) Horn:



3. Test the horn by connecting power to the A or B terminals and ground to the other. The horn should sound.



4. If the horn fails to sound, replace it.

Security/Low Horn:

