


# Power Seats

## Seat Switch Test

**CAUTION:** Be careful not to damage the seats, the interior trim or the body.

- 1. Remove the two screws, then remove the power seat switch from the power seat.
- 2. Disconnect the 5P connectors from each power seat switch.
- 3. Check for continuity between the terminals, in each switch position, according to the table.



Terminal		3	5	4	2	1
Position						
SLIDE	FORWARD		○—○		○—○	
	NEUTRAL	○				○
	BACKWARD	○				○
RECLINE	FORWARD	○		○—○		○
	NEUTRAL	○				○
	BACKWARD		○—○		○—○	