


Headlights

Bulb Replacement

CAUTION:

- Halogen headlights can become very hot in use; do not touch them or the attaching hardware immediately after they have been turned off.
- Do not try to replace or clean the headlights with the lights on.

1. Remove the bulb cap.




2. Disconnect the 2P connector, then remove the retaining spring and bulb.

Daytime Running Lights (Canada)

Replacement

1. Remove the bolt, and pull out the daytime running light, then disconnect the 2P connector.



2. If necessary, replace the bulb.

