


Dash Sensor Removal

CAUTION:

- Do not damage the sensor wiring.
- Do not install used SRS parts from another car. When repairing an SRS, use only new parts.
- Carefully inspect the dash sensors for signs of being dropped or improperly handled, such as dents, cracks or deformation.

1. Disconnect the battery negative cable, then the positive cable.
2. Before disconnecting any part of the SRS wire harness, install the short connectors (RED) (see page 24-10).
3. Remove the dashboard lower cover.
4. Pull back the carpeting, and disconnect the 2P connector between the dash sensor and SRS main harness.



5. Remove the two dash sensor mounting bolts from the sensor bracket, then remove the dash sensor.

