

Lift and Support Points

Lift and Safety Stands

CAUTION:

- If ground clearance is inadequate to clear the shop lift, either;
 - Install rubber spacers on the coil springs to raise the vehicle. Use the floor jack procedures to raise the vehicle (page 1-11).
 - or
 - Remove the chin spoiler,
 - or
 - If you need even more clearance, install the rubber spacers and remove the chin spoiler.
- Follow the lift manufacturer's instructions.
- Use rubber pad adapters on the lift to avoid damaging the vehicle.

Spacer Installation

1. Place the rubber contact pads as shown.
2. Raise the lift a few inches, and rock the vehicle to be sure it is firmly supported.
3. Raise the lift to full height, and inspect the lift points for solid support.
4. Install rubber spacers on the coil springs.

NOTE: Use the same support points to support the vehicle on safety stands.

CAUTION: Remove the rubber spacers after lowering the vehicle. Do not drive the vehicle with rubber spacers installed between the spring.

