


# Bearing Outer Race

## Replacement (Torque Converter Housing Side)

### NOTE:

- The outer race and bearing should be replaced as a set.
- Inspect and adjust the bearing preload whenever the bearing is replaced.

1. Remove the bearing outer race, 90 mm washer, and oil guide ring using the special tools.



2. Install the oil guide ring and 90 mm washer, then drive the outer race into the torque converter housing using the special tools.

