


Linear Solenoid

Test

1. Remove the linear solenoid connector.
2. Measure the resistance between the A and B terminal.

STANDARD: 5.0-5.5 (at 70°F, 20°C)



3. Replace the linear solenoid if resistance is out of specification.
4. Connect the No. 3 terminal of the linear solenoid connector to the battery positive terminal and the No. 1 terminal to the battery negative terminal. A clicking sound should be heard.
5. If not, replace the linear solenoid.