

**CAUTION: (if roof maintenance is required)**

- **Be careful not to bend the edge of the roof opening.**
- **The roof is made of aluminum alloy. Take care not to dent or scratch the roof. If there is a minor dent or scratch on the roof, repair the roof with putty (refer to the body repair manual).**
- **When replacing the component parts of the roof, place the roof on an appropriate pad to prevent damage.**

**NOTE:**

- Have an assistant help remove the roof.
- When the roof is stored on the engine cover, lock the roof cover securely.
- When installing the roof, secure it by turning both roof side lock handles. Make sure they are locked securely.