

# Headlights




## Headlight Replacement

### ⚠ CAUTION

Headlights become very hot during use; do not touch them or any attaching hardware immediately after they have been turned off.


1. Open the hood.
2. Disconnect the connectors from the headlight.
3. Remove the front bumper (see [section 20](#)).



4. Remove the two mounting bolts, then remove the headlight assembly.
5. Install the headlight in the reverse order of removal.
6. After replacement, adjust the headlights to local requirements (see page [23-48](#)).

## HID Inverter Unit Replacement

1. Combination light switch OFF.
2. Disconnect the battery negative cable, then disconnect the positive cable.
3. Remove the headlight.
4. Remove the three mounting screws from the HID inverter unit.
5. Disconnect the connectors, then remove the HID inverter unit from the headlight.



6. Install the HID inverter unit in the reverse order of removal.
7. After replacement, adjust the headlights to local requirements (see page [23-48](#)).