




Engine Compartment Lid Switch Test

1. Open the engine compartment lid.
2. Disconnect the 2P connector from the engine compartment lid switch.
3. Check continuity at the switch connector terminals.
 - There should be continuity between the terminals with the lever released (lid open).
 - There should be no continuity with the lever pushed down (lid closed).



Hood Switch Test

1. Open the hood.
2. Disconnect the 2P connector from the hood switch.
3. Check continuity at switch connector terminals.
 - There should be continuity between the terminals with the lever released (hood open).
 - There should be no continuity with the lever pushed down (hood closed).

