


System Description

Electrical Connections



FUSES

- ① BRAKE LIGHTS HORN (20A)*
- ② THL MOTOR (20A)**
- ③ CLOCK (7.5A)*
- ④ ACG (120A)**
- ⑤ ACG(S) (20A)**
- ⑥ IG COIL (30A)**
- ⑦ No. 2 FUEL PUMP SRS2 (15A)***
- ⑧ No. 5 BACK-UP LIGHTS

ALTERNATOR

TURN SIGNALS (15A)***


- ⑨ STARTER SIGNAL (7.5A)**
- ⑩ AIR PUMP (60A)**
- ⑪ O2 SENSOR HEATER (10A)*
- ⑫ IG SW (50A)*


- * : In the under-hood fuse/relay box
- ** : In the engine compartment fuse/relay box
- *** : In the under-dash fuse box

(cont'd)

System Description

Electrical Connections (cont'd)





TERMINAL LOCATIONS


ECM A (26P)													ECM B (16P)								ECM C (12P)						ECM D (22P)											
1	2	3	4	5	6	7	8	9	10	11	12	13	1	2	3	4	5	6	7	8	1	2	3	4	5	6	1	2	3	4	5	6	7	8	9	10	11	
14	15	16	17	18	19	20	21	22	23	24	25	26	9	10	11	12	13	14	15	16	7	8	9	10	11	12	12	13	14	15	16	17	18	19	20	21	22	


ECM F (26P)													ECM G (12P)				
1	2	3	4	5	6	7	8	9	10	11	12	13	1	2	3	4	5
14	15	16	17	18	19	20	21	22	23	24	25	26	6	7	8	9	10

(cont'd)

System Description

Electrical Connections (cont'd)







(cont'd)

System Description

Electrical Connections (cont'd)







(cont'd)

System Description

Electrical Connections (cont'd)







(cont'd)

System Description

Electrical Connections (cont'd)







(cont'd)

System Description

Electrical Connections (cont'd)





(cont'd)

System Description

Electrical Connections (cont'd)

