



Oil Seal

Installation


-  The seal surface on the block should be dry.
Apply a light coat of oil to the crankshaft and to the lip of the seal.

1. Using the special tools, drive in the flywheel-end seal until the driver bottoms against left side cover.



2. Confirm clearance is equal all the way around with a feeler gauge.

Clearance: 0.2 – 0.5 mm (0.008 – 0.020 in)



NOTE: Refer to page 8-9 for installation of the oil pump side oil seal.