




## Retractor Switch Test

1. Remove the retractor switch (see page 23-186).
2. Check for continuity between the terminals in each switch position according to the table.


Retractor Switch

Terminal Position	A		B		C	D
OFF						
ON						

RETRACTOR SWITCH



Retractor Switch



## Retractor Switch Light Bulb Replacement

1. Remove the retractor switch (see page 23-186).
2. Turn the bulb 45° counterclockwise to remove it.

