

Specifications

Standards and Service Limits

Cylinder Head/Valve Train

'97 Model	3-2
'98 Model	3-2a
'99 Model	3-2b
'00 Model	3-2c
'01 Model	3-2d
'02 Model	3-2e
'03 Model	3-2f
'04 Model	3-2g
'05 Model	3-2h

Engine Block

'97 Model	3-3
'98 Model	3-3a
'99 Model	3-3b
'00 Model	3-3c
'01 Model	3-3d
'02 Model	3-3e
'03 Model	3-3f
'04 Model	3-3g
'05 Model	3-3h

Engine Lubrication

'97 Model	3-3
'98 Model	3-3a
'99 Model	3-3b
'00 Model	3-3c
'01 Model	3-3d
'02 Model	3-3e
'03 Model	3-3f
'04 Model	3-3g
'05 Model	3-3h

Cooling

'97 Model	3-4
'98 Model	3-4a
'99 Model	3-4b
'00 Model	3-4c
'01 Model	3-4d
'02 Model	3-4e
'03 Model	3-4f
'04 Model	3-4g
'05 Model	3-4h

Fuel and Emissions

'97 Model	3-4
'98 Model	3-4a
'99 Model	3-4b
'00 Model	3-4c
'01 Model	3-4d
'02 Model	3-4e

'03 Model	3-4f
'04 Model	3-4g
'05 Model	3-4h

Clutch

'97 Model	3-4
'98 Model	3-4a
'99 Model	3-4b
'00 Model	3-4c
'01 Model	3-4d
'02 Model	3-4e
'03 Model	3-4f
'04 Model	3-4g
'05 Model	3-4h

Manual Transmission

'97 Model	3-5
'98 Model	3-5a
'99 Model	3-5b
'00 Model	3-5c
'01 Model	3-5d
'02 Model	3-5e
'03 Model	3-5f
'04 Model	3-5g
'05 Model	3-5h

Automatic Transmission

'97 Model	3-7
'98 Model	3-7a
'99 Model	3-7b
'00 Model	3-7c
'01 Model	3-7d
'02 Model	3-7e
'03 Model	3-7f
'04 Model	3-7g
'05 Model	3-7h

Differential

'97 Model	M/T 3-10 A/T 3-10
'98 Model	M/T 3-10a A/T 3-10a
'99 Model	M/T 3-10b A/T 3-10b
'00 Model	M/T 3-10c A/T 3-10c

'01 Model	M/T 3-10d A/T 3-10d
-----------	------------------------

'02 Model	M/T 3-10e A/T 3-10e
-----------	------------------------

'03 Model	M/T 3-10f A/T 3-10f
-----------	------------------------

'04 Model	M/T 3-10g A/T 3-10g
-----------	------------------------

'05 Model	M/T 3-10h A/T 3-10h
-----------	------------------------

Steering

'97 Model	3-11
'98 Model	3-11a
'99 Model	3-11b
'00 Model	3-11c
'01 Model	3-11d
'02 Model	3-11e
'03 Model	3-11f
'04 Model	3-11g
'05 Model	3-11h

Suspension

'97 Model	3-11
'98 Model	3-11a
'99 Model	3-11b
'00 Model	3-11c
'01 Model	3-11d
'02 Model	3-11e
'03 Model	3-11f
'04 Model	3-11g
'05 Model	3-11h

Brakes

'97 Model	3-11
'98 Model	3-11a
'99 Model	3-11b
'00 Model	3-11c
'01 Model	3-11d
'02 Model	3-11e
'03 Model	3-11f
'04 Model	3-11g
'05 Model	3-11h

Air Conditioning

'97 Model	3-12
'98 Model	3-12a
'99 Model	3-12b
'00 Model	3-12c
'01 Model	3-12d
'02 Model	3-12e
'03 Model	3-12f
'04 Model	3-12g
'05 Model	3-12h

Electrical

'97 Model	3-12
'98 Model	3-12a
'99 Model	3-12b
'00 Model	3-12c
'01 Model	3-12d
'02 Model	3-12e
'03 Model	3-12f
'04 Model	3-12g
'05 Model	3-12h

Design Specifications

'97 Model	3-13
'98 Model	3-13a
'99 Model	3-13b
'00 Model	3-13c
'01 Model	3-13d
'02 Model	3-13e
'03 Model	3-13f
'04 Model	3-13g
'05 Model	3-13h

Body Specifications

'97 Model	3-16
'98 Model	3-16a
'99 Model	3-16b
'00 Model	3-16c
'01 Model	3-16d
'02 Model	3-16e
'03 Model	3-16f
'04 Model	3-16g
'05 Model	3-16h