


Maintenance

Transmission Oil

1. Check the oil at normal operating temperature (the cooling fan comes on), engine OFF, and the vehicle on level ground.
2. Remove the oil filler plug, then check the level and condition of the oil.



3. The oil level must be up to the fill hole. If it is below the hole, add oil until it runs out, then reinstall the oil filler plug.
4. If the transmission oil is dirty, remove the drain plug, and drain the oil.
5. Reinstall the drain plug with a new washer, and refill the transmission with the recommended oil to the proper level.
6. Reinstall the oil filler plug with a new washer.


NOTE: The drain plug washer should be replaced at every oil change.

Oil Capacity

2.65 l (2.80 US qt, 2.33 Imp qt) at oil change.

2.90 l (3.06 US qt, 2.55 Imp qt) at overhaul.

Always use Genuine Honda Manual Transmission Fluid (MTF). Using motor oil can cause stiffer shifting because it does not contain the proper additives.





Back-up Light Switch Neutral Position Switch



Replacement

NOTE: To check the switch, see [section 23](#).

1. Disconnect the connector, then remove the switch connector from the connector clamp.
2. Remove the switch.



3. Apply liquid gasket (P/N 08718-0001) to the switch threads, then install the switch.