


Wiper/Washer

Windshield Wiper Motor Replacement

1. Open the hood, and remove the cap nuts and the wiper arms. Don't let the wiper arms hit the hood.
2. Remove the windshield lower molding, hood seal and cowl cover by prying off the trim clips and removing the screws (see page 23-295).
3. Disconnect the 5P connector from the wiper motor assembly, then remove the two mounting bolts and the wiper linkage assembly.

WIPER LINKAGE ASSEMBLY




5P CONNECTOR

4. Remove the three mounting bolts and nut from the wiper linkage assembly, and remove the wiper motor.

NUT
18 N-m (1.8 kgf-m, 13 lbf-ft)

MOUNTING
BOLTS
8 N-m (0.8 kgf-m,
5.8 lbf-ft)



5. Install the wiper motor assembly in the reverse order of removal.