



Bulb Replacement

Headlight High Beam:

1. Open the hood.
2. Turn the bulb socket 45° counterclockwise, remove it from the headlight assembly.




3. Disconnect the 2P connector from the bulb socket, then replace the bulb.



Front Turn Signal Light:

1. Open the hood.
2. Turn the bulb socket 45° counterclockwise, remove it from the headlight assembly, then replace the bulb.



Front Parking Light:

1. Open the hood.
2. Turn the bulb socket 45° counterclockwise, remove it from the headlight assembly, then replace the bulb.

