



Wiper/Washer

Windshield Wiper/Washer Switch Test

- 1. Remove the dashboard lower cover (see page 23-296).
- 2. Disconnect the 20P connector from the floor wire harness.
- 3. Check for continuity between the terminals in each switch position according to the table.



Terminal	A	B	C		O		P	Q	R	S
Position										
INT	○									○
LO		○	→	←					○	
HI		○	→	←	○					
MIST switch "ON"		○	→	←	○	→			○	
Washer switch "ON"	○			→			○			
Intermittent dwell time controller turned			○			0-10kΩ		○		