




Motor Test

CAUTION: Be careful not to damage the seats, the interior trim or the body.

1. Remove the power seat, then disconnect the 2P connector from the slide motor.
2. Remove the two screws, then remove the power seat switch from the power seat.
3. Disconnect the 5P connector from the power seat switch (recline switch side).



4. Test motor operation.

CAUTION: When the motor stops running, disconnect power immediately.

FORWARD

SLIDE: Connect battery power to the No. 6 terminal and ground to the No. 7 terminal.

BACKWARD

SLIDE: Connect battery power to the No. 7 terminal and ground to the No. 6 terminal.

FORWARD

RECLINE: Connect battery power to the No. 4 terminal and ground to the No. 1 terminal.

BACKWARD

RECLINE: Connect battery power to the No. 1 terminal and ground to the No. 4 terminal.

NOTE: If a motor does not run, reverse the power and ground connections. If the motor still does not run, the motor or the wire harness is faulty.