


SRS Unit Removal

CAUTION:

- Always keep the short connectors on the airbags when the harness is disconnected.
- Do not damage the SRS unit terminals or connectors.
- Do not disassemble the SRS unit; it has no serviceable parts.
- Store the SRS unit in a clean, dry area.
- Do not use any SRS unit which has been subjected to water damage or shows signs of being dropped or improperly handled, such as dents, cracks or deformation.

1. Disconnect the battery negative cable, then the positive cable.
2. Before disconnecting any part of the SRS wire harness, install the short connectors (RED) (see page 24-10).
3. Pull down the carpeting from the front console.



4. Disconnect the SRS unit connector, then unclip the SRS main harness from the holders.
5. Remove the four SRS unit mounting bolts.
6. Pull the SRS unit out from the passenger's side.

