


Illustrated Index

Torque Converter Housing/Valve Body





- ① ATF STRAINER
- ② O-RING Replace.
- ③ ACCUMULATOR COVER
- ④ LOCK WASHER Replace.
- ⑤ SERVO DETENT BASE
- ⑥ SERVO BODY
- ⑦ SERVO SEPARATOR PLATE
- ⑧ CHECK BALLS (7/32) #7
- ⑨ SECONDARY VALVE BODY FILTER Replace.
- ⑩ SECONDARY VALVE BODY
- ⑪ SECONDARY SEPARATOR PLATE
- ⑫ DOWEL PIN
- ⑬ LOCK-UP VALVE BODY
- ⑭ LOCK-UP SEPARATOR PLATE
- ⑮ DOWEL PIN
- ⑯ REGULATOR VALVE BODY
- ⑰ O-RING Replace.
- ⑱ STATOR SHAFT ASSEMBLY
- ⑲ STOPPER PIN
- ⑳ MAIN VALVE BODY FILTER Replace.
- ㉑ CHECK BALLS (7/32) #7
- ㉒ MAIN VALVE BODY
- ㉓ ONE-WAY RELIEF VALVE SPRING
- ㉔ ONE-WAY RELIEF VALVE
- ㉕ ATF PUMP DRIVEN GEAR
- ㉖ ATF PUMP DRIVE GEAR
- ㉗ ATF PUMP DRIVEN GEAR SHAFT
- ㉘ DOWEL PIN

- ㉙ MAIN SEPARATOR PLATE
- ㉚ TORQUE CONVERTER CHECK VALVE
- ㉛ TORQUE CONVERTER CHECK VALVE SPRING
- ㉜ ATF LUBRICATION PIPE
- ㉝ 2ND ACCUMULATOR BODY
- ㉞ LSD RELIEF VALVE SPRING
- ㉟ LSD RELIEF VALVE
- ㊱ CONTROL SHAFT
- ㊲ CONTROL LEVER
- ㊳ OIL SEAL Replace.
- ㊴ LOCK WASHER Replace.
- ㊵ CHANGE SHAFT
- ㊶ CHANGE SHAFT CAP
- ㊷ SHIFT CONTROL SOLENOID VALVE ASSEMBLY
- ㊸ SHIFT CONTROL SOLENOID FILTER/GASKET Replace.
- ㊹ LOCK-UP CONTROL SOLENOID VALVE ASSEMBLY
- ㊺ LOCK-UP CONTROL SOLENOID FILTER/GASKET Replace.
- ㊻ VEHICLE SPEED SENSOR ASSEMBLY
- ㊼ O-RING Replace.
- ㊽ SECONDARY SHAFT NEEDLE BEARING Replace.
- ㊾ ATF GUIDE PLATE Replace.
- ㊿ COUNTERSHAFT NEEDLE BEARING Replace.
- ① ATF GUIDE PLATE Replace.
- ② MAINSHAFT BALL BEARING Replace.
- ③ MAINSHAFT OIL SEAL Replace.
- ④ SEALING WASHER Replace.
- ⑤ 4TH ATF GUIDE PLATE/PIPE
- ⑥ 3RD ATF GUIDE PLATE

TORQUE SPECIFICATION

No.	TORQUE VALUE	BOLT SIZE	REMARKS
A	12 N·m (1.2 kgf·m, 8.7 lbf·ft)	6 x 1.0 mm	OIL PRESSURE CHECK BOLT
B	18 N·m (1.8 kgf·m, 13 lbf·ft)	8 x 1.25 mm	
C	14 N·m (1.4 kgf·m, 10 lbf·ft)	6 x 1.0 mm	
D	29 N·m (3.0 kgf·m, 22 lbf·ft)	8 x 1.25 mm	