


Ignition System

Idle Speed Inspection

- 1. Start the engine. Hold the engine at 3,000 rpm with no load (A/T in **N** or **P** position, M/T in neutral) until the radiator fan comes on, then let it idle.
- 2. Connect a tachometer to the test tachometer connector.



- 3. Check the idle speed with all electrical systems turned OFF.

Idle Speed (rpm):

M/T	A/T
800 ± 50 (In neutral)	780 ± 50 (In N or P)

- 4. Adjust the idle speed if necessary (see [section 11](#)).

Ignition Control Module (ICM) Replacement

- 1. Disconnect the 8P and 6P connectors from the ignition control module (ICM).
- 2. Remove the two mounting bolts, and slide the ICM out toward the front side. Be careful not to damage the vacuum hoses when removing the ICM.

