



Mainshaft, Countershaft, Differential Assemblies

Removal

1. Remove the change holder assembly from the clutch housing.



2. Tape the mainshaft splines to protect them, then remove the mainshaft assembly and countershaft assembly with the shift fork from the clutch housing.





3. Remove the differential assembly from the clutch housing.

