

General Information

Chassis and Paint Codes

'97 Model	
U.S. Model	1-2
Canada Model	1-3
'98 Model	
U.S. Model	1-2a
Canada Model	1-3a
'99 Model	
U.S. Model	1-2b
Canada Model	1-3b
'00 Model	
U.S. Model	1-2c
Canada Model	1-3c
'01 Model	1-2d
'02 Model	1-2e

'03 Model	1-2f
'04 Model	1-2g
'05 Model	1-2h

Identification Number Locations

'97-99 Models	1-9
'00 Model	1-4c
'01 Model	1-3d
'02 Model	1-3e
'03 Model	1-3f
'04 Model	1-3g
'05 Model	1-3h

Warning/Caution Label Locations

'97 Model	1-5
'98-04 Models	1-4a

Under-hood Emission Control Label

'97 Model	1-9
'98 Model	1-7a
'99 Model	1-4b

'00 Model	1-5c
'01 Model	1-4d
'02 Model	1-4e
'03 Model	1-4f
'04 Model	1-4g
'05 Model	1-4h

Lifts and Support Points

Lift and Safety Stands	1-10
Floor Jack	1-11

Towing

1-12

Service Precautions

Handling of Special Nuts and Bolts	1-13
Handling of Tires	1-13
Engine Steam Cleaning (NSX-T only)	1-13