


# System Description

## Electrical Connections



\* : In the under-hood fuse/relay box


\*\* : In the engine compartment fuse/relay box


\*\*\* : In the under-dash fuse box

(cont'd)

# System Description

## Electrical Connections (cont'd)





# TERMINAL LOCATIONS

## ECM A (26P)

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

## ECM B (16P)

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16

## ECM C (12P)

1	2	3	4	5	6
7	8	9	10	11	12

## ECM D (22P)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

## ECM F (26P)

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26


## ECM G (12P)


1	2	3	4	5
6	7	8	9	10
11	12	13	14	15

(cont'd)

# System Description

## Electrical Connections (cont'd)







(cont'd)

# System Description

## Electrical Connections (cont'd)







(cont'd)

# System Description

## Electrical Connections (cont'd)









(cont'd)

# System Description

## Electrical Connections (cont'd)







(cont'd)

# System Description

## Electrical Connections (cont'd)





# System Description

## Electrical Connections (cont'd)

