


Cruise Control


Component Location Index

SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS ([section 24](#)) before performing repairs or service.





ECM
See [section 11](#)



VEHICLE SPEED SENSOR (VSS)
Test, page [23-131](#)

