


# Safety Indicator

## Component Location Index

SRS components are located in this area. Review the SRS component locations, precautions, and procedures in the SRS [section 24](#) before performing repairs or service.



## Description

### Safety Indicator System:

LEDs are used to indicate when the trunk lid, engine compartment lid, a door, or the roof is not latched, or when a brake light is faulty, or when the roof is not stored or improperly stored in its holder. The LEDs will go on and stay on for about two seconds after the ignition switch has been turned ON (II) to show that the system circuit is functioning.

### Brake Light Bulb Failure Indicator:

If all brake light bulbs are OK, the indicator light stays off because the ORN/WHT wire is grounded by the two brake light failure sensors connected in series. With the brake lights off, the ground is provided through the diode, the failure sensor relay coils, and bulb filaments. With the brake light on, all four relays (two in the left sensor, two in the right sensor), connected in series, supply ground. If any of the four bulbs is not working, the chain is broken and the ORN/WHT wire is not longer grounded. The indicator light comes on.